

APPLICATION INSTRUCTIONS

These settings is to be viewed as general recommendations. You will always get the best result by testing our products with your particular heat press. We use our Hot 2000 heat press for the majority of all our tests.

It is easy to apply our heat transfer on textiles, but there's a few tips and tricks to make sure that you get the best result possible every single time.



STARK SOLID

- 1 Pre-heating:** (Recommended)
Time: 5 sec.
Temp: 160° C
Preassure: 4-7 bar
- 2 Application:**
Time: 15 sec.
Temp: 160° C
Preassure: 4-7 bar
- 3 Remove the plastic carrier hot/cold**



STARK PROCESS

- 1 Pre-heating:** (Recommended)
Time: 5 sec.
Temp: 160° C
Preassure: 4-7 bar
- 2 Application:**
Time: 15 sec.
Temp: 160° C
Preassure: 4-7 bar
- 3 Remove the plastic carrier hot/cold**



STARK REFLEX

- 1 Pre-heating:** (Recommended)
Time: 5 sec.
Temp: 160° C
Preassure: 4-7 bar
- 2 Application:**
Time: 15 sec.
Temp: 160° C
Preassure: 4-7 bar
- 3 Remove the plastic carrier cold!**

SKUREN REFLEX

- 1 Pre-heating:** (Recommended)
Time: 5 sec.
Temp: 130° C
Preassure: 4-7 bar
- 2 Application:**
Time: 15 sec.
Temp: 130° C
Preassure: 4-7 bar
- 3 Remove the plastic carrier immediately!**